

Refratechnik Steel GmbH Am Seestern 5 40547 Düsseldorf Germany Phone: +49 211 5858 0 Fax: +49 211 5858 49 steel@refra.com

www.refra.com

Processing instructions V 100 **REFRACAST**® basic liquefied casting compound

<u>Note</u>: Please read the product information sheet first, to ensure that these are the right processing instructions for your product. This document describes the procedure for processing dense **liquefied magnesia-based REFRACAST**® refractory concretes.

The instructions contained in this document must be complied with during processing and installation of the respective refractory concrete. Modification of or deviations from the processing instructions can lead to major problems during installation, and possibly to total failure of the installed refractory material. These instructions provide general guidelines for storage, processing, and installation of the specific refractory material. If, due to specific site conditions, it appears necessary to deviate from the procedures described here, please consult Refratechnik Steel GmbH before starting work.

Storage

- In general: Store under cool, dry, and frost-free conditions.
- The shelf life stated in the product information sheet is valid from the production date, and only if storage is in accordance with our recommendations.
 The production date is stated on the packaging label.
- Under certain circumstances, material
 that has been properly stored may still
 be usable even after expiry of the stated
 shelf life. In such a case, conduct a setting test with a sample before using the
 material. In case of doubt, the expired
 material can be checked by Refratechnik
 Steel GmbH.
- Incorrect storage can greatly reduce shelf life, and can impair product quality.
- Never use the contents of a packaging unit if it contains lumps that cannot be crumbled manually. Lumps indicate prematurely cured material, thereby making the entire packaging unit unusable.

- The original pallet wrapping foil should be left intact for as long as possible to protect the product. However, the foil is not a substitute for storage under cover.
- Also standing water, e.g. due to inadequate drainage of the storage area, can damage the material.
- Stacking of the goods supplied by us (in sacks, Big Bags, etc.) is done under the sole responsibility of the shipping company or customer. Refratechnik Steel GmbH accepts no liability for possible consequential damage (damaged packaging, personal injury, etc.).

Health and safety

- Always wear suitable safety goggles, dust mask, protective clothing, and working gloves.
- Always wash thoroughly after working with the material.
- Observe the information in the safety data sheet.

General information

- This product is a hydraulically setting refractory concrete. Delivered dry in 25 kg sacks or in Big Bags, it is mixed with water on site, and then cast. Curing occurs at room temperature.
- Always mix complete packaging units (1 sack or 1 Big Bag). The use of partial quantities can lead to demixing and changed material properties.
- Only use clean drinking water, as otherwise the setting behaviour may be affected.
- Low temperatures can retard or even stop the setting process. Therefore, the temperature of material and mixing water must be at least 5 °C. In some cases, it might be necessary to heat the installation area.
- On the other hand, the setting process may be significantly accelerated at temperatures above 25 °C.
- Please take the expansion of the refractory material for your specific furnace application into account. The reversible and irreversible expansion values and



the respective material properties are given in the product information sheet. Depending on the furnace operating conditions and the specific characteristics of the refractory material, any arising stresses and pressures must be compensated by suitably designed expansion joints.

- During installation of the monolithic refractory material, please ensure correct anchoring to the existing furnace structure and/or to the existing or adjacent refractory material (e.g. with steel anchors, ceramic anchoring systems, etc.).
- Suitable measures must be taken to ensure that the water or water vapour generated during the drying & heat-up process is removed from the refractory lining without pressure build-up.
- With certain kiln structures and refractory linings, the drying process can cause the generated water or water vapour to diffuse outwards in the direction of the furnace shell instead of inwards to the hot side (kiln chamber). Therefore, suitable measures must be taken to ensure that the water or water vapour can escape to atmosphere. For this purpose, 10-mm holes drilled into the kiln's outer steel shell (at least 5 per m²) have proved to be successful.
- Regarding the build-up of water vapour pressure, attention must be given to the entire wall structure of the lining (wear lining/permanent lining/insulation). In the area behind the wear lining, it must also be ensured that only such materials are used, which provide an adequate (highest possible) permeability to the steel shell.
- If the permanent lining/insulating layers are used several times and only the wear lining is replaced, they can become clogged in the course of time due to moisture transport with dust contaminations, salts, etc., thereby also impeding moisture transport. Consequently, multiple use of such layers must be seen as counterproductive in terms of dewater-

ing performance. It might even be safer also to replace the permanent lining, in order to ensure perfect flowthrough to the cold side.

 To ensure a continuous drying process, the complete kiln chamber must always be flushed with an adequate amount of fresh air during the entire drying and heat-up procedure. The air circulating in the kiln chamber may never be saturated with moisture.

Mixing

- Mixer, tools, conveying equipment, etc. must be clean and free from any form of contamination.
- Use of a positive mixer is preferable, but not essential.
- Mix only as much material at a time, as can be processed within about 20 minutes.
- Data on the maximum and minimum amounts of water to be added is given in the product information sheet or on the packaging label.
- First, briefly mix the dry material for about 30 seconds to restore the consistency after any demixing that might have occurred during transport.
- Next, add the minimum amount of water while continuing to mix the material.
 Continue mixing for about 2 minutes until a thorough mix is obtained.
- Frequently, the required consistency is obtained only at the end of the mixing period, because the fine portions in the product must be broken down first.
 Therefore, you should wait until the full mixing time has elapsed, and don't try to obtain the required consistency in a shorter time by adding more water. The material's consistency can change quite abruptly from "too dry" to "exactly right". If necessary, the remaining amount of water can be added until the required consistency is achieved. Here-

by, the maximum amount of water may not be exceeded.

 Then continue mixing for about 2 more minutes.

Processing

- If using formwork, make sure it is sufficiently stable, and that its surfaces are smooth. Use formwork release oil.
- Casting should be done within 15 minutes after mixing (at an ambient temperature of 5...25 °C).
- While casting the concrete, no moisture may be drawn out of the material by adjacent dry and absorbent surfaces.
- Therefore, any existing refractory lining should be pre-wetted. Any moisturesensitive materials, such as insulation, should be covered with foil.
- While casting the material, or shortly afterwards, the concrete must be compacted by rodding or vibration (e.g. with an internal vibrator).
- If an internal vibrator is used, continue the vibration only until no further compaction is evident. To prevent air inclusions, withdraw the vibrator slowly from the concrete.
- The formation of an even and clear surface indicates good compaction. Never use a trowel to smooth the surface.
- Depending on layer thickness and heating-up time, it may be advisable to provide evaporation holes (not in areas subjected to the liquid phase).

Setting and curing

 Generally, it takes between 6 and 12 hours before the concrete has cured sufficiently to permit removal of the formwork. Ambient temperatures in midsummer may considerably shorten this time, while winter temperatures or the



use of material stored in cold places may lengthen it.

 Of course, the formwork may only be removed after the material has fully cured. The right time to do this can be determined reliably by means of a «ring test»: Lightly strike the accessible face of the lining with a small hammer. As curing proceeds, the tone changes from «dull» to «bright». A bright tone, which no longer changes, is generally an indication that the formwork may be removed.

<u>Caution</u>: In some cases, the lining core may not yet be solidified, even though the outer face of the casting is fully set. If in doubt, always allow the full recommended curing time of 24 hours.

 Full setting of the refractory concrete requires at least 24 hours. Until that time, the concrete must be protected from frost.

Drying and heating up

- Normally, formwork can be removed between 12 and 24 hours after casting the product. This period can be longer in cold conditions.
- Because of the high hydration tendency of raw magnesia materials, the monolithic lining must be de-molded, dried or heated up as soon as possible after setting.
- In some cases, however, an earlier start of drying and heating up may be acceptable. Please contact Refratechnik Steel GmbH in such cases.
- Excessively fast heating up can result in binder faults, spalling, and crack forma-

tion. For precise control, thermocouples should be fitted on the hot side. To establish a suitable heating-up profile for your plant, please consult Refratechnik Steel GmbH.

- The following guiding values can be used for a standard installation up to 150 mm thick, without products that need additional drying:
 - From room temperature up to 150 °C: 15 °C/h
 - Holding time at 150 °C: 1 h per 10 mm layer thickness
 - From 150 up to 350 °C: 15 °C/h
 - Holding time at 350 °C: 1 h per 10 mm layer thickness
 - From 350 up to 600 °C: 15 °C/h
 - Holding time at 600 °C: 1 h per 10 mm layer thickness
 - From 600 °C up to application temperature: 25 °C/h

3